

X-Rite OEM i1Display

CalMAN Quick-Start Guide

- 1. All the software you need is available for download from the SpectraCal web site, www.spectracal.com. No additional drivers are required for this meter as it uses Windows standard HID drivers.**
- 2. Install CalMAN**
Download and run the CalMAN msi, (Version 4.5 or higher) and Windows Installer will install CalMAN on your hard drive. The installer will ask you to accept the license agreement.
- 3. Plug the OEM i1Display into a USB port in your system and install the driver**
When you plug in your *OEM i1Display*, Windows will pop up a Found New Hardware Wizard. Windows will install the necessary drivers automatically.
- 4. Start CalMAN and select the OEM i1Display**
On the right side panel, select Meter Settings, click search. When the progress indicator is finished you can select the meter via the drop down box.
- 5. Modes of use.**
The *OEM i1Display* comes with an included diffuser for use when taking ambient light measurements or reading direct light sources such as reading a projector in direct view mode. In all other modes the diffuser is not used.

