



Using the SpectraCal C3 with CalMAN Quick-Start Guide

1. Install the SpectraCal [Device Driver Kit](#), available for download from the SpectraCal web site, www.spectracal.com.

2. Plug the C3 into a USB port on your computer
When you plug your C3 into a computer USB port, Windows will pop up the Found New Hardware Wizard. The drivers can be automatically installed by Windows.



Note: The driver identifies the meter as ColorMunki Smile. This is proper.

3. **Install CalMAN**
Download and run the CalMAN installer. The Installer will ask you to accept the license agreement and will install CalMAN on your hard drive.
4. **Start CalMAN and select the C3 meter**
On the CalMAN Meter Settings tab, click *Find Meter*, then click *Search* (maintain the All Meters selection in the search dialog). When the progress indicator finishes, the C3 meter will be the actively selected meter.
5. **Select Meter Mode (Target Display Type)**
The C3 is intended for flat panel calibration only. This includes LCD, LED and plasma displays.